


ASPEN-TLSO 464 Thoracic Lumbar Sacral Orthotic

Waist/Hip Band



Back panel


1. Open the brace and center the back panel on patient's back **as low** as possible.



Sternal pad


Abdominal panel

2. Wrap brace around patient and center abdominal panel and sternal pad on the front of patient. Make sure the brace fits tightly around midsection of body.




3. Pull tabs away from body to achieve a proper fit. After pulling place tabs on brace.


Straps



Attach straps to sternal pad. Pull the straps to tighten them. Straps can be positioned to fit over or under the shoulders.



Straps can be positioned to fit over or under the shoulder



If buckles are needed attach buckles to strap ends and attach buckle to the top of the brace back panel.

Make sure after taking off brace that you release and reset the tabs. To do this release tabs and with the brace open pull taught on ends of the Waist/Hip Band and the tabs will retract.